

8. Color on navigation screen is unusual (RGB signal error).

INSPECTION PROCEDURE

1 Display check mode (Color bar check).

NG

Replace the multi display.

2 Navigation check mode (Color bar check).

NG

Go to step 4.

OK

3 Check the screen setting. (Day or Night mode)

OK

Normal.

NG

4 Check the navigation ECU power source circuit (see page [DI-1244](#)).

NG

Replace or repair wire harness or connector.

OK

5	Check the display signal circuit (see page DI-1258).
---	---

NG**Replace or repair wire harness or connector.****OK****Replace the multi-display.**