BRAKE

SST (Special Service Tools)

PP2AA–02

	09023–00100 Union Nut Wrench 10 mm	
	09318–12010 Transfer Bearing Adjusting Nut Wrench	
	09630–00014 Power Steering Gear Housing Overhaul Tool Set	
	(09631–00142) Overhaul Stand	
	09709–29018 LSPV Gauge Set	
	09717–20010 Brake Shoe Return Spring Remover	
	09718–20010 Brake Shoe Return Spring Replacer	
	09843–18020 Diagnosis Check Wire	
	09950–60010 Replacer Set	
	(09951–00180) Replacer 18	
	(09951–00190) Replacer 19	
	09990–00150 ABS Actuator Checker and Sub–harness	

	09990–00240	ABS Actuator Checker Sheet ”G”	
	09990–00480	ABS Actuator Checker Sub–harness ”S”	