


ENGINE

HOW TO PROCEED WITH TROUBLESHOOTING

DIDY0-01

When using the intelligent tester II, troubleshoot in accordance with the procedure on the following pages.



When not using intelligent tester II, troubleshoot in accordance with the procedure on the following pages.

