

DTC	P0605/17	Interior IC Malfunction
------------	-----------------	--------------------------------

DTC	P1633/89	Interior IC Malfunction
------------	-----------------	--------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
P0605/17 P1633/89	ECU malfunction	• Engine ECU

INSPECTION PROCEDURE

HINT:

Read freeze frame data using the intelligent tester II. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, and other data from the time the malfunction occurred.

Replace engine ECU.