D RELAY LOCATIONS

: Cowl Side J/B LH	LHD : Left Kick Panel (See Page 9)
	RHD : Left Kick Panel (See Page 10)

(Inner Circuit : See Page 24)