

D RELAY LOCATIONS

 : Cowl Side J/B RH	LHD : Right Kick Panel (See Page 9)
	RHD : Right Kick Panel (See Page 10)

(Inner Circuit : See Page 36)

