


E ELECTRICAL WIRING ROUTING

Position of Parts in Body

[RHD : Swing Type]



- | | | | |
|------|------------------------------------|-----|------------------------------|
| P 7 | Parking Brake SW | R25 | Rear Door Speaker RH |
| P 8 | Power Outlet (Luggage Compartment) | R26 | Rear Evaporator Temp. Sensor |
| P 11 | Power Window Control SW Front LH | R27 | Rear Heater Blower Motor |
| P 13 | Power Window Control SW Rear LH | R28 | Rear Heater Blower Resistor |
| P 14 | Power Window Control SW Rear RH | R30 | Rear Heater Power Transistor |
| P 15 | Power Window Master SW | R31 | Rear Heater Relay |
| P 17 | Power Window Motor Front LH | R32 | Rear Inlet Air Temp. Sensor |
| P 18 | Power Window Motor Front RH | R33 | Rear Interior Light |
| P 19 | Power Window Motor Rear LH | R34 | Rear Personal Light |
| P 20 | Power Window Motor Rear RH | R37 | Rear Window Defogger LH |
| P 21 | Pretensioner LH | R38 | Rear Window Defogger LH |
| P 22 | Pretensioner RH | R39 | Rear Window Defogger RH |
| | | R40 | Rear Window Defogger RH |
| R 13 | Rear A/C Control SW | R42 | Rear Wiper Motor LH |
| R 14 | Rear Air Mix Control Servo Motor | R43 | Rear Wiper Motor RH |
| R 15 | Rear Combination Light LH | R44 | Rear Wiper Relay |
| R 17 | Rear Combination Light RH | R47 | Remote Control Mirror ECU |
| R 19 | Rear Cooler Blower Motor | R48 | Remote Control Mirror LH |
| R 20 | Rear Cooler Magnetic Valve | R49 | Remote Control Mirror RH |
| R 21 | Rear Cooler Power Transistor | R50 | Room Temp. Sensor (Rear) |
| R 22 | Rear Cooler Relay | R58 | Rain Sensor |
| R 23 | Rear Diff. Lock Motor | R59 | Rear Cooler Blower Resistor |
| R 24 | Rear Door Speaker LH | R60 | Rear Fog Light |