



LOCATION



Engine Room R/B
 ● EFI Fuse
 ● EFI and ECD Relay



H

1085326