

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during DTC check, find the circuit corresponding to the code in the table below and proceed to the appropriate page.

DTC No. (See Page)	Circuit Inspection	Trouble Area
B1221 (DI-1105)	Power Window Switch Circuit on Driver Door	• Wire harness • Power Window Master Switch (Driver door ECU)
B1222 (DI-1105)	Door Lock Switch Circuit on Driver Door	• Door lock switch • Door key lock and unlock switch • Wire harness • Power Window Master Switch (Driver door ECU)
B1231 (DI-1107)	Jam Protection Limit Switch Circuit on Driver Door	• Jam protection limit switch • Wire harness • Power Window Master Switch (Driver door ECU)
B1232 (DI-1109)	Jam Protection Pulse Switch Circuit on Driver Door	• Jam protection pulse switch • Wire harness • Power Window Master Switch (Driver door ECU)