

# DRIVER DOOR CONTROL SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

DIB57-01

### HINT:

The ECU is connected to the multiplex communication system. Therefore, be sure to check that there is no troubles in the the multiplex communication system before performing the troubleshooting.

