

26. Any speaker does not work. (DVD sound only)

INSPECTION PROCEDURE

- | | |
|---|---|
| 1 | Check wire harness and connector between DVD auto changer and radio receiver (See page IN-36). |
|---|---|

NG

Repair or replace wire harness or connector.

OK

Check and replace the DVD auto changer.