

6. Screen cannot be dimmed in night time.

INSPECTION PROCEDURE

- | | |
|---|--|
| 1 | Check if the screen is dimmed at night. (With the light control switch ON), do all screens except the navigation screen appear in Night Mode?) |
|---|--|

NG

Check the light control switch.

OK

- | | |
|---|--------------------------|
| 2 | Check the multi display. |
|---|--------------------------|

CHECK:

Measure the voltage between terminals DR and GND1 of the multi-display.

OK:

DR: Above 9 V

NG

Replace or repair wire harness.

OK

- | | |
|---|---|
| 3 | Check multi-display power source circuit (see page DI-1255). |
|---|---|

NG

Replace or repair wire harness.

OK

Replace the multi display.