

9. Black screen appears when "MAP", "Menu" or "DESTINATION" switch pressed.

INSPECTION PROCEDURE

1

Check the navigation ECU power source circuit (see page [DI-1252](#)).

NG

Replace or repair wire harness or connector.

OK

2

Check the display signal circuit (see page [DI-1266](#)).

NG

Replace or repair wire harness or connector.

OK

Replace the multi-display.