


Position of Parts in Body



- A 32 A/C Amplifier (Rear)
- A 33 A/C Amplifier (Rear)
- A 34 A/C Amplifier (Rear)
- A 35 ABS Speed Sensor Rear LH
- A 36 ABS Speed Sensor Rear RH
- A 58 Accumulator Solenoid

- B 2 Back Door Courtesy SW
- B 3 Back Door Key Lock and Unlock SW
- B 4 Back Door Lock Motor , Back Door Unlock Detection SW

- C 29 Curtain Shield Airbag Squib LH
- C 30 Curtain Shield Airbag Squib RH
- C 36 Control Valve Assembly

- D 10 Door Courtesy Light Front LH
- D 11 Door Courtesy Light Front RH
- D 12 Door Courtesy Light Rear LH
- D 13 Door Courtesy Light Rear RH
- D 14 Door Courtesy SW Front LH
- D 15 Door Courtesy SW Front RH
- D 16 Door Courtesy SW Rear LH
- D 17 Door Courtesy SW Rear RH
- D 18 Door Key Lock and Unlock SW LH
- D 19 Door Key Lock and Unlock SW RH
- D 20 Door Lock Control SW RH
- D 21 Door Lock Motor Front LH , Door Unlock Detection SW Front LH
- D 22 Door Lock Motor Front RH , Door Unlock Detection SW Front RH
- D 23 Door Lock Motor Rear LH , Door Unlock Detection SW Rear LH
- D 24 Door Lock Motor Rear RH , Door Unlock Detection SW Rear RH
- D 27 Door Control Receiver
- D 29 Damping Force Control Actuator Front LH
- D 30 Damping Force Control Actuator Front RH
- D 31 Damping Force Control Actuator Rear LH
- D 32 Damping Force Control Actuator Rear RH

- F 8 Front Door Speaker LH
- F 9 Front Door Speaker RH
- F 10 Front Interior Light , Rear Personal Light
- F 11 Front Personal Light
- F 12 Fuel Pump , Fuel Sender

- H 11 High Mounted Stop Light
- H 15 Height Control Sensor Rear

- I 22 Inner Mirror

- J 22 Junction Connector
- J 23 Junction Connector
- J 25 Junction Connector
- J 26 Junction Connector

- L 1 License Plate Light LH
- L 2 License Plate Light RH
- L 5 Canister Pump Module






















- M 2 Moon Roof Control ECU
- M 3 Moon Roof Control SW

Position of Parts in Body

- N 2 Navigation ECU
- N 3 Navigation ECU
- N 4 Navigation ECU

- O 5 Overhead J/B

Position of Parts in Body



Position of Parts in Body

