

1996 to 2004 MY ECM Power Supply Monitor (P0560, P1600)

To return to monitor description, see page [Ce-83](#).

MONITOR STRATEGY

Required sensors/Components	Main	ECM
	Sub	None
Frequency of operation	Continuous	
Duration	3 sec.	
MIL operation	Immediate	
Sequence of operation	None	

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not present	See page In-39
--	--------------------------------

TYPICAL MALFUNCTION THRESHOLDS

Detection Criteria	Threshold
Battery voltage to ECM	Less than 3.5 V