

1998 to 2004 MY ETCS Monitor (P1129, P2119)

To return to monitor description, see page [Ce-77](#).

MONITOR STRATEGY

Required sensors/Components	Main	Throttle position sensor
	Sub	None
Frequency of operation	Continuous	
Duration	Within 2 sec.	
MIL operation	Immediate	
Sequence of operation	None	

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not present	See page In-39
--	--------------------------------

TYPICAL MALFUNCTION THRESHOLDS

Detection Criteria	Threshold
Difference between target throttle position and current throttle position	0.3 V or more