

Pressure Control Solenoid "E" Electrical (Shift Solenoid Valve SLN) Monitor Description

MONITOR SUMMARY

The shift solenoid valve SLN controls the oil pressure to the accumulator control valve to reduce transmission gearshift shock.

The ECM judges the appropriate oil pressure based on the signals from the throttle position sensor, the output speed sensor and the input speed sensor, and adjusts the oil pressure by sending a duty-ratio signal to the shift solenoid valve SLN.

The ECM illuminates the MIL and sets a DTC when it detects an open or a short circuit malfunction in the shift solenoid valve SLN.

RELATED DTC

Previous code:

Related DTCs	P1765	Shift solenoid valve SLN/Range check
--------------	-------	--------------------------------------

Extended code:

Related DTCs	P2725	Shift solenoid valve SLN/Range check
--------------	-------	--------------------------------------

MODEL YEAR CHART

Model Year	DTC	See Page
1996	P1765	Cm-393
1997	P1765	Cm-394
1998	P1765	Cm-395
1999	P1765	Cm-396
2000	P1765	Cm-397
2001	P1765	Cm-398
2002	P1765	Cm-400
2003	P2725	Cm-401