

Brake Switch

Ct00C-02

Brake Switch "B" Circuit High Monitor Description

MONITOR SUMMARY

This circuit prevents the engine from stalling when the vehicle is suddenly braked while the torque converter is in the lock-up condition. The ECM receives the signal from the stop light switch at the time brake pedal is depressed. Then, the ECM stops sending the "lock-up" command to the lock-up solenoid valve and the torque converter clutch "unlocks". The ECM monitors the brake light switch "B" signal. If the ECM detects that the switch remains ON while the vehicle is in "stop and go" driving conditions*, it will illuminate the MIL and a DTC is set.

RELATED DTC

Previous code:

Related DTCs	P1520	Stop light switch/Range check/Rationality
--------------	-------	---

Extended code:

Related DTCs	P0724	Stop light switch/Range check/Rationality
--------------	-------	---

MODEL YEAR CHART

Model Year	DTC	See Page
1998	P1520	Ct-98
2001	P1520	Ct-99
2002	P1520	Ct-100
2003	P0724 P1520	Ct-101
2004	P0724	Ct-102