

1996 and 1997 MY EGR Valve Monitor (P0403)

To return to monitor description, see page [Eg-44](#).

MONITOR STRATEGY

Required sensors/Components	Main	EGR valve (stepper motor)
	Sub	Crankshaft position sensor, Throttle position sensor, Vehicle speed sensor, A/C switch
Frequency of operation	Continuous	
Duration	10 sec.	
MIL operation	Immediate	
Sequence of operation	None	

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not present	See page In-39
--	--------------------------------

TYPICAL MALFUNCTION THRESHOLDS

Detection Criteria	Threshold
EGR valve drive duty	100 %