





LOCATION OF BODY ELECTRICAL PARTS








Relay Block**Relays**

- | | |
|----------------------------|----------------------------|
| A. Taillight Control Relay | D. Turn Signal Flasher |
| B. Front Drive Relay | E. Headlight Control Relay |
| C. Front Heater Relay | F. Ignition Main Relay |

Fuse Block**Fuses**

1. HEAD (RH)	15A	11. A/C	10A
2. TAIL	15A	12. GAUGE	7.5A
3. TURN	7.5A	13. DOOR	15A
4. DOOM	7.5A	14. ENGINE	10A
5. HEAD (LH)	15A	15. -	
6. STOP	15A	16. SPARE	7.5A
7. WIPER	20A	17. EFI	15A
8. CHARGE	7.5A	18. IGN	7.5A
9. CIG	15A	19. DEFOG	20A
10. HAZ-HORN	15A	20. SPARE	15A

Circuit Breakers

A. Heater	30A
B. Power	30A