

## ABBREVIATIONS USED IN THIS MANUAL

|                |                                   |
|----------------|-----------------------------------|
| A/C            | Air Conditioner                   |
| AI             | Air Injection                     |
| ALH            | Automatic Locking Hub             |
| ASV            | Air Switching Valve               |
| A/T, ATM       | Automatic Transmission            |
| ATF            | Automatic Transmission Fluid      |
| B <sub>0</sub> | Overdrive Brake                   |
| B <sub>2</sub> | Second Brake                      |
| BTDC           | Before Top Dead Center            |
| BV             | By-pass Valve                     |
| BVSV           | Bimetal Vacuum Switching Valve    |
| C <sub>1</sub> | Front Clutch                      |
| C <sub>2</sub> | Rear Clutch                       |
| DP             | Dash Pot                          |
| ECU            | Electronic Controlled Unit        |
| EFI            | Electronic Fuel Injection         |
| EGR            | Exhaust Gas Recirculation         |
| ESA            | Electronic Spark Advance          |
| EVAP           | Evaporative (Emission Control)    |
| EX             | Exhaust (manifold, valve)         |
| Ex.            | Except                            |
| FIPG           | Formed in Place Gasket            |
| IG             | Ignition                          |
| IN             | Intake (manifold, valve)          |
| ISC            | Idle Speed Control                |
| LSP            | Load Sensing Proportioning        |
| Max.           | Maximum                           |
| MP             | Multipurpose                      |
| O/D            | Overdrive                         |
| O / S          | Oversize                          |
| PCV            | Positive Crankcase Ventilation    |
| PS             | Power Steering                    |
| SSM            | Special Service Materials         |
| SST            | Special Service Tools             |
| STD            | Standard                          |
| SW             | Switch                            |
| TDC            | Top Dead Center                   |
| TWC            | Three-way Catalyst                |
| U / S          | Undersize                         |
| VCV            | Vacuum Control Valve              |
| VSV            | Vacuum Switching Valve            |
| VTV            | Vacuum Transmitting Valve w/ With |
| w/o            | Without                           |