


DESCRIPTION

The generator is a small, high speed, high performance type with an IC regulator incorporated. The IC regulator uses integrated circuits and controls the voltage produced by the generator.



P09059

PRECAUTIONS

1. Check that the battery cables are connected to the correct terminals.
2. Disconnect the battery cables when the battery is given a quick charge.
3. Do not perform tests with a high voltage insulation resistance tester.
4. Never disconnect the battery while the engine is running.

CH00J-04