

EMISSION CONTROL SYSTEMS

SYSTEM PURPOSE

EG05T-06

System	Abbreviation	Purpose
Positive crankcase ventilation Evaporative emission control Exhaust gas recirculation Pulsed secondary air injection Three-way catalytic converter Sequential multiport fuel injection*	PCV EVAP EGR PAIR TWC SFI	Reduces blow-by gas (HC) Reduces evaporative HC Reduces NOx Reduces CO and HC Reduces CO, HC and NOx Regulates all engine conditions for reduction of exhaust emissions.

* For inspection and repair of the SFI system, refer to the SFI section.

V02007

PREPARATION

EG05V-01

RECOMMENDED TOOLS

	09082-00015 TOYOTA Electrical Tester	
---	--------------------------------------	--

EG05W-04

EQUIPMENT

Heater	TVV
Thermometer	TVV
Tachometer	
Torque wrench	
Vacuum gauge	

EG05X-04

SSM (SPECIAL SERVICE MATERIALS)

08833-00070 Adhesive 1324, THREE BOND 1324 or equivalent	TVV
---	-----