





PREPARATION


SST (SPECIAL SERVICE TOOLS)

BR018-06

	09023-00100 Union Nut Wrench 10 mm	
	09703-30010 Brake Shoe Return Spring Tool	Rear drum brake
	09709-29017 LSPV Gauge Set	
	09717-20010 Brake Shoe Return Spring Remover	
	09718-00010 Shoe Hold Down Spring Driver	Rear drum brake
	09718-20010 Brake Shoe Return Spring Replacer	
	09737-00010 Brake Booster Push Rod Gauge	
	09751-36011 Brake Tube Union Nut 10 x 12 mm Wrench	
	09843-18020 Diagnosis Check Wire	w/ ABS
	09990-00150 ABS Actuator Checker and Sub-harness	w/ ABS
	09990-00163 ABS Actuator Checker Sheet "A"	w/ ABS
	09990-00200 ABS Actuator Checker Sub-harness "C"	w/ ABS
	09990-00210 ABS Actuator Checker Sub-harness "E"	w/ ABS

BR0FN-02

RECOMMENDED TOOLS

	09082-00050 TOYOTA Electrical Tester Set	
	09905-00013 Snap Ring Pliers	

BR017-05

EQUIPMENT

Torque wrench	
Micrometer	Brake disc
Dial indicator	Brake disc
Vernier calipers	Brake drum and disc

BR018-05

LUBRICANT

Item	Capacity	Classification
Brake fluid	–	SAE J 1703 or F'MVSS No.1 16 DOT 3