







PREPARATION

SST (SPECIAL SERVICE TOOLS)

EG07P-04

	09032-00100 Oil Pan Sea(Cutter	
	09213-5801 2 Crankshaft Pulley Hoolding Tool	
	09213-60017 Crankshaft Pulley & Gear Puller Set	
	(09213-00020) Body With Bolt	
	(09213-00030) Handle	
	(09213-00040) Bolt Set	
	09228-44011 Oil Filter Wrench	
	09316-60010 Transmission & Transfer Bearing Replacer	
	(09316-00010) Replacer Pipe	Crankshaft front oil seal
	(09316-00050) Replacer 'D'	Crankshaft front oil seal
	09330-00021 Companion Flange Holding Tool	Crankshaft pulley
	09950-20017 Universal Puller	

EG070-03

RECOMMENDED TOOLS

	09200-00010 Engine Adjust Kit	
---	-------------------------------	--

EG07R-04

EQUIPMENT

Oil pressure gauge	
Precision straight edge	Oil pump
Torque wrench	

EG07S-09

LUBRICANT

Item	Capacity	Classification
Engine oil Dry fill Drain and refill w/ Oil filter change w/o Oil filter change	8.0 liters (8.5 US qts, 7.0 Imp. qts) 7.4 liters (7.8 US qts, 6.5 Imp. qts) 6.9 liters (7.3 US qts, 6.1 Imp. qts)	API grade SG or SH, Energy-Conserving II or ILSAC multigrade and recommended viscosity oil

EG07T-02

SSM (SPECIAL SERVICE MATERIALS)

08826-00080 Seal packing or equivalent	Oil pump Oil pan (Timing chain cover)
08833-00080 Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	Oil pressure switch