




PREPARATION

SA02W-01

SST (SPECIAL SERVICE TOOLS)

	09308-00010 Oil Seal Puller	
	09514-35011 Rear Wheel Bearing Puller	
	09^08-20012 Front Hub & Drive Pinion Bearing Tool Set	
	(09608-03020) Handle	
	(09608-03060) Replacer	
	(09608-03090) Replacer	
	09^50-17011 Hub Bolt Remover	

SA02X-01

EQUIPMENT

Dial indicator	
Torque wrench	