

GENERAL DESCRIPTION

Care must be taken to replace parts properly because they could affect the performance of the steering system and result in a driving hazard.

TROUBLESHOOTING

Use the below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

See page	SA-167	SA-167	SR-23	-	SA-72	-	-	SR-37	SA-13
Parts Name	Tires (Improperly inflated)	Front wheel alignment (Incorrect)	Fluid level (Low)	Steering system joints (Worn)	Suspension arm ball joints (Worn)	Steering column (Binding)	Sliding yoke (Worn)	Steering gear housing	Front wheel bearing (Worn)
Trouble									
Hard steering	1	4	2	5	6	7		8	
Poor return	1	2				3		4	
Excessive play				1	2		3	5	4
Abnormal noise			1	2				3	