


PREPARATION

ST008-09

SST (SPECIAL SERVICE TOOLS)

	09286-46011 Injection Pump Spline Shaft Puller	Armature bearing
	09820-00030 Alternator Rear Bearing Replacer	Armature rear bearing

RECOMMENDED TOOLS

ST007-04

	09082-00050 TOYOTA Electrical Tester Set	
---	--	--

EQUIPMENT

ST00U-04

Dial indicator	Commutator
Magnetic finger	
Pull scale	Brush spring
Sandpaper	Commutator
Torque wrench	
V-block	
Vernier calipers	Commutator, Brush

ON-VEHICLE INSPECTION

NOTICE: Before changing the starter, check the following items again:

- Connector connection
- Accessory installation, e.g.: theft deterrent system

ST05K-02