

DTC P0121 Throttle Pedal Position Sensor Switch “A” Circuit Range Performance Problem

CIRCUIT DESCRIPTION

Refer to throttle position circuit malfunction on page [EG-258](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0121	When closed throttle position switch is ON, condition (a) continues: (2 trip detection logic) (a) VTA > 2.0 V	Throttle position sensor

INSPECTION PROCEDURE

