

PRECAUTION

Be careful not to grip the propeller shaft tube too tightly in the vise as this will cause deformation.

PREPARATION

SST (SPECIAL SERVICE TOOLS)

	09332-25010 Universal Joint Bearing Remover & Replacer	
---	--	--

EQUIPMENT

Torque wrench	
---------------	--

TROUBLESHOOTING

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

See Page	PR – 5		PR-4	-	PR – 5	PR – 5	
	Parts Name	Trouble	Sleeve yoke spline worn	Propeller shaft runout	Propeller shaft imbalance	Sleeve yoke spline stuck	Spider bearing worn or stuck
Noise			1				2
Vibration				2	3	1	