



REAR AXLE

PREPARATION

SST (SPECIAL SERVICE TOOLS)

	09223-15020 Oil Seal & Bearing Replacer	Oil seal installation
	09308-00010 Oil Seal Puller	
	09509-25011 Rear Axle Bearing Lock Nut Wrench	
	09517-36010 Rear Axle Shaft Oil Seal Replacer—	
	09608-35014 Axle Hub & Drive Pinion Bearing Tool Set	Bearing outer race installation
	(09608-06020) Handle—	
	(09608-06110) Front Hub Inner & Drive Pinion Front Bearing Cup Replacer—	
	(09608-06210) Rear Axle Bearing Replacer	

EQUIPMENT

Dial indicator	
Torque wrench	
Spring tension gauge	