
STARTING SYSTEM

PREPARATION

SST (SPECIAL SERVICE TOOLS)

	09286 – 46011 Injection Pump Spline Shaft Puller	Armature bearing
	09820 – 00030 Alternator Rear Bearing Replacer	Armature rear bearing

RECOMMENDED TOOLS

	09082 – 00050 TOYOTA Electrical Tester Set.	
---	---	--

EQUIPMENT

Dial indicator	Commutator
Magnetic finger	Steel ball
Pull scale	Brush spring
Sandpaper	Commutator
Torque wrench	
V-block	Commutator
Vernier calipers	Commutator, Brush

ON-VEHICLE INSPECTION

NOTICE: Before changing the starter, check these items again:

- Connector connection
- Accessory installation, e.g.: theft deterrent system