


FROM POWER SOURCE SYSTEM (SEE PAGE 52)



SERVICE HINTS

A21 AUTO ANTENNA CONTROL SW
4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
2-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A 8	22	F11	25	J 8	25
A21	24	J 3	25		


□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IF1	32	COWL WIRE AND INSTRUMENT PANEL WIRE (INSTRUMENT PANEL CENTER)


▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	32	RIGHT KICK PANEL

A 8 GRAY




A21 BLACK



F11

(SEE PAGE 20)

J 3 BLUE



(HINT : SEE PAGE 7)

J 8 BLUE



(HIT : SEE PAGE 7)