




REMOVAL


1. REMOVE ROOF DRIP MOULDING

Using SST, pull off the roof drip moulding from front ends.

SST 09806-30010

2. REMOVE FRONT DOOR BELT MOULDING (See page [BO-9](#))

3. REMOVE REAR DOOR BELT MOULDING (See page [BO-15](#))



4. REMOVE QUARTER BELT MOULDING

Pry out the clips from the edge of the panel, and remove the moulding.

○ : 4 clips

BO5153