





DISASSEMBLY

1. Slide Type:

REMOVE CENTER SASH

Remove the screw and weatherstrip.



2. REMOVE QUARTER WINDOW GLASS

Pull up the sash and remove the 2 glasses.

3. REMOVE QUARTER WINDOW GLASS RUN FROM SASH

4. REMOVE QUARTER WINDOW WEATHERSTRIP FROM SASH