

## INSTALLATION

Installation is in the reverse order of removal (See page [BR-34](#)).

HINT:

After installation, fill brake reservoir with brake fluid, bleed brake system (See page [BR-4](#)) and check for leaks.