

TORQUE SPECIFICATION

Part tightened		N·m	kgf·cm	ft·lbf
Valve body x Transmission case		10	100	7
Oil stainer x Valve body		10	100	7
Oil pan		7.4	75	65 in.·lbf
Drain plug x Oil pan		20	205	15
Parking lock pawl bracket x Transmission case		7.4	75	65 in.·lbf
Front propeller shaft x Front differential		74	750	54
Front propeller shaft x Transfer		74	750	54
Rear propeller shaft x Transfer		88	900	65
Rear propeller shaft x Rear differential		88	900	65
Drive plate x Crankshaft		98	1,000	72
Torque converter clutch x Drive plate		55	550	40
Front exhaust pipe x Exhaust manifold		62	630	46
Front exhaust pipe x TWC		39	400	29
Oil cooler pipe		34	350	25
Transmission x Engine		71	730	53
Exhaust pipe clamp		19	195	14
Park/neutral position switch	Nut	6.9	70	61 in.·lbf
	Bolt	13	130	9
No. 2 vehicle speed sensor		5.4	55	48 in.·lbf
Speedometer driven gear sleeve x Locking plate		16	160	12
Starter mounting bolt		39	400	29
Transfer shift lever		18	185	13
Stabilizer bar bracket mounting bolt		18	185	13
Engine under cover mounting bolt		28	290	21
Exhaust pipe No. 1 support bracket x Torque converter clutch housing		24	240	17
Crossmember x Frame		61	620	45
Engine rear mounting x Crossmember		74	750	54
Transmission shift lever assembly x Body		5.4	55	48 in.·lbf
Oil cooler mounting bolt		11	115	8