

REAR HEATER SWITCH

AC28Q-01

REMOVAL

1. REMOVE INSTRUMENT CLUSTER FINISH CENTER PANEL WITH A/C CONTROL ASSEMBLY
2. REMOVE REAR HEATER SWITCH