




FRONT DOOR BELT MOULDING REMOVAL

B038B-01

REMOVE FRONT DOOR BELT MOULDING

(See page [B0-36](#))

Pry out the clip from the edge of the panel, and remove the moulding.