




QUARTER BELT MOULDING REMOVAL

B038F-01

REMOVE QUARTER BELT MOULDING (See page [BO-36](#))

Pry out the clips from the edge of the panel, and remove the moulding.