

DTC	23	Vehicle Speed Signal Abnormal
------------	-----------	--------------------------------------

CIRCUIT DESCRIPTION

(See page [DI-305](#))

DTC No.	Detection Item	Trouble Area
23	Vehicle speed sensor pulse is abnormal. (When speed signal is not input to the ECU below 0.2 sec., code will be displayed.)	- Vehicle speed sensor - Cruise control ECU

WIRING DIAGRAM

(See page [DI-305](#))

INSPECTION PROCEDURE

1	Check vehicle speed sensor (See page BE-34).
---	---

NG

Replace vehicle speed sensor.

OK

Check and replace cruise control ECU
(See page [IN-27](#)).