
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
IN1	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IN2	
IN3	
IN4	
IO1	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IO2	