
Position of Parts in Body

[RHD : 3–Door]



A 42 ABS Speed Sensor Rear

B 10 Back Door Courtesy SW
B 11 Back Door Key Lock and Unlock SW
Back Door Lock Motor
Back Door Unlock Detection SW

C21 Curtain Shield Airbag Squib LH
C22 Curtain Shield Airbag Squib RH

D 9 Detection SW (Rear Diff. Lock)
D10 Door Control Receiver
D 11 Door Courtesy Light Front LH
D12 Door Courtesy Light Front RH
D15 Door Courtesy SW Front LH
D16 Door Courtesy SW Front RH
D19 Door Key Lock and Unlock SW Front LH
Door Lock Motor Front LH
Door Unlock Detection SW Front LH
Double Door Lock Motor Front LH
Position SW Front LH
D20 Door Key Lock and Unlock SW Front RH
Door Lock Motor Front RH
Door Unlock Detection SW Front RH
Double Door Lock Motor Front RH
Position SW Front RH
D21 Door Lock Control SW
Power Window Master SW

F 14 Front Door Speaker LH
F 15 Front Door Speaker RH
F 16 Front Door Squawker LH
F 17 Front Door Squawker RH
F 18 Front Door Tweeter Speaker LH
F 19 Front Door Tweeter Speaker RH
F 20 Fuel Pump
F 22 Fuel Sender

H19 High Mounted Stop Light

I 15 Interior Light

J 27 Junction Connector
J 28 Junction Connector
J 29 Junction Connector
J 30 Junction Connector
J 31 Junction Connector
J 33 Junction Connector