

W
L–Y
B–R
W–L
W–R
W
R–L
ACC
AM1
IG1
ST1
AM2
IG2
ST2
I14
Ignition SW
ID
7. 5A
GAUGE
IG
B 7
Body ECU
L
Charge
C 9(A), C12(D)
Combination Meter
J23
Junction
Connector
GR
(*1)
(*2)
50A AM1
140A ALT (w/ PTC)
120A ALT (w/o PTC)
30A AM2
7. 5A ALT–S
D7
IC4
IL2
B
Battery

∗ 1 : w/ Daytime Running Light
∗ 2 : w/o Daytime Running Light

