

ACC
IG1
ST1
AM1
AM2
IG2
ST2
I14
Ignition SW
B–W
W–L
W–R
G (LHD)
R (RHD)
50A AM1
120A ALT
30A AM2
STA Relay
(LHD)
(RHD)
B–Y
W
Y
W–B
Y–G
B–R
B
EA1
IM5
J18
Junction Connector
Combination Meter
IL3
L–Y
(*1 M/T)
B–Y
(*1 A/T)
(*2)
(*1)
J 2(A), J 3(B)
Junction Connector
S 4(A), S 5(B)
Starter
M
Battery
EB

∗ 1 : Unleaded Gasoline
∗ 2 : Leaded Gasoline

