

Viscous Heater




From Power Source System (See Page 128)
7. 5A
VISCUS
40A
PTC–1
40A
PTC–2
40A
PTC–3
B–W
B–W
BR–W
B–R
L
(LHD)
L–W
(RHD)
W
R–B
(*1)
R–Y
(*1)
R–W
(*1)
R–B
(*1)
R–W
(*1)
R–Y
(*1)
IC2
IM1
IM1
IM1
PTC–1
Relay
PTC–2
Relay
PTC–3
Relay
BR–W
R–Y
(*1)
R–W
(*1)
R–B
(*1)
W–B
L
W–B
B–R
W–B
B–Y
+B
PTC3
PTC2
PTC1
IM2
IM2
IM2
IGN
GND
V12
Viscous Heater Amplifier
B–W
W–B
B
B
W–B
B
B
W–B
L
B–R
B–Y
J6
Junction
Connector
L
B–R
W–B
IC2
PTC1
PTC2
PTC3
P 6(A), P 7(B)
PTC Heater
E
E
W
W
I 7
I 7
W
W–B
B1
IN4
B–W
A
J24
Junction
Connector
W–B
IN
BP

Viscous Heater

