

J POWER SOURCE (Current Flow Chart)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other Parts.





* 1:w/ Daytime Running Light
* 2:w/o Daytime Running Light
* 3:w/ PTC
* 4:w/o PTC
* 5:w/ VSC
* 6:w/o VSC

[LOCATION]

① : Driver Side J/B

(See Page 26 (LHD), 28 (RHD))

② : Engine Room R/B (See Page 23)

③ : Engine Room R/B No.3 (See Page 24)