
# Connector Joining Wire Harness and Wire Harness




| Code | Joining Wire Harness and Wire Harness (Connector Location) |
|---|---|
| ID1 | Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel) |
| ID2 | |
| IE1 | Roof Wire and Instrument Panel Wire (Left Side of the Driver Side J/B) |
| IF1 | Instrument Panel Wire and Instrument Panel Wire (Near the Center J/B No.1) |
| IF2 | Instrument Panel Wire and Instrument Panel Wire (Right Kick Panel) |
| IG1 | Instrument Panel No.3 Wire and Instrument Panel Wire (Near the Combination Meter) |
| IH1 | Instrument Panel Wire and Instrument Panel No.2 Wire (Instrument Panel Brace LH) |
| II1 | Console Box Wire and Instrument Panel Wire (Under the Instrument Panel Brace LH) |
| II2 | |