
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
IJ1	Instrument Panel Wire and Switch Wire (Front Side of the Console Box)
IK1	Console Box Wire and A/C Sub Wire (Rear Side of the Console Box)
IL1	Engine Wire and Instrument Panel Wire (Left Side of the Blower Unit)
IL2	
IL3	
IL4	
IM1	Instrument Panel Wire and Engine Room Main Wire (Right Kick Panel)
IM2	
IM3	
IM4	
IM5	