

43 LAND CRUISER / LAND CRUISER PRADO
Power Source
Option Connector (Wireless Door Lock Control)
* 1 : 1GR–FE
* 2 : Except 1GR–FE
1
2
3
4
Left Kick Panel
J24 Junction Connector
W–B
O 3 Option Connector (Door Control Receiver)
GR–G
Body ECU <2–29>
G
Body ECU <2–29>
Turn Signal Flasher <25–3>
W
R–G
Interior Lights <2–7>
Engine Control System <11–3>
ACC CUT Relay
L
IM1
O 2 Option Connector (Keyless Buzzer)
LG–B
J20 Junction Connector
GR
(*1)
IC4
A12
C12
7. 5A ACC
W–G
GR
(*2)
R
Body ECU <2–11>
10A DOME
W–L
Short Pin
Battery
B
I14 Ignition SW
ACC
IG1
ST1
AM1
50A AM1
140A ALT
W